

SOCIAL DISTANCING SIGNAGE FITTING INSTRUCTIONS

PLEASE ENSURE THESE INSTRUCTIONS ARE FOLLOWED WHEN INSTALLING YOUR SIGNAGE

Before applying indoor floor or wall graphics, the surface needs to be clean, dry, smooth, non-porous and free from polluting agents like grease, dirt, or silicone. If required, use strong detergent to clean. For best adhesion we recommend surfaces are rubbed down with a solution of 1 part Isopropanol to 2 parts water.

HOW TO GUARANTEE THE BEST RESULTS:

- If installing floor graphics make sure you thoroughly rinse and dry the floor before the decals are applied.
- Install graphics soon after cleaning the area - ensuring its totally dry but before it gets dirty again!
- Aim for a location temperature of between 15°C (59°F) and 25°C (77°F).
- If necessary secure the graphic at one end with 50mm masking tape.
- Pull back a section of the backing sheet and using a soft cloth stick an edge of the decal to the surface. Gradually pull the backing sheet off as you continue to smooth down the graphic taking care to avoid air bubbles.
- Once the decal is in position firmly rub down the surface making sure all edges are securely adhered to the floor.
- With floor graphics wait at least 24 hours before cleaning the floor.

If you have recently painted the surface to receive the decals please contact us before you install them.



OFFSITE DIGITAL
EXTRAORDINARY PRINT